



NOTE:

1. REFER TO FIRESTONE WEBSITE FOR MOST CURRENT INFORMATION.
2. INSTALL FIRESTONE TERMINATION BAR WITH 1/4" (6 mm) GAP BETWEEN ADJOINING SECTIONS.
3. TERMINATION BAR MUST BE CUT AT INSIDE AND OUTSIDE CORNERS. **DO NOT BEND AROUND CORNERS.**
4. FASTEN TERMINATION BAR WITHIN 1" (25 mm) MAX. OF ALL SECTION ENDS.
5. APPLY WATER BLOCK IN A 3/8" (10 mm) TO 1/2" (13mm) BEAD AT APPROXIMATELY 10 LF PER TUBE.

MASONRY AND CONCRETE WALLS / CURBS MUST BE WATERPROOFED AND MAINTAINED IN ORDER FOR ANY SURFACE MOUNTED TERMINATION TO BE EFFECTIVE.

Firestone Firestone Building Products	TERMINATION WITH TERMINATION BAR		MAXIMUM WARRANTY: 20 Years	
	RUBBERGARD™ EPDM	ACCEPTABLE SYSTEMS: ALL	ISSUE / REVISION DATE: 09/24/2018	DETAIL NO. T-1
Firestone Building Products Sales: (800- 428-4442 Technical (800) 428-4511 www.firestonebpco.com			NOT TO SCALE	